O3.2-175

Ruggedized Electrostatic Radionuclide Aerosol Collection as Part of RASA 2.0

Michael Swanwick, Clive Devoy, Katharine Fergusson, Jessica Elliott, Sheldon Stokes, Kenneth McEnaney reare

Michael Swanwick (mxs@creare.com) Creare LLC, Hanover, NH, USA

Presentation Date: 09 09 2025



Michael Swanwick, Clive Devoy, Katharine Fergusson, Jessica Elliott, Sheldon Stokes, Kenneth McEnaney Presenter: Michael Swanwick mxs@creare.com, Creare LLC, Hanover, NH, USA

O3.2-175

Introduction to Creare's Facilities and People

- Contract Engineering R&D
 - Creating New Technology and Products
 - Diverse Technical Experience
 - Extensive Facilities
- Industrial and U.S. Federal Client Base
- Founded in 1961
- Located in Hanover, NH, USA
- Privately Held
- Commercialization
 - Licensing/Partnering
 - Spin-Off Companies
 - Custom Products







- Total Staff 175+
- 70+ Engineers (55% Ph.D., 30% M.S.)
 - Disciplines

Mechanical	Materials
Electrical	Aerospace
Nuclear	Physics
Chemical	Biomedical

Schools

MIT	Brown	Case Western
Purdue	Princeton	Ohio State
Stanford	Michigan	Clarkson
Cornell	Texas	Wisconsin
Virginia	Virginia Tech	Dartmouth
Caltech	RPI	Minnesota

 40+ Technical Staff (30% B.S., 30% A.S.)

> Mechanical Technicians Electronics Technicians Machinists Drafters/Designers Computer Specialists Inspectors/QA

This work is sponsored by U.S. Defense Threat Reduction Agency (DTRA)
SBIR Contract # HDTRA223C0004
DISTRIBUTION STATEMENT: Cleared for Release



Michael Swanwick, Clive Devoy, Katharine Fergusson, Jessica Elliott, Sheldon Stokes, Kenneth McEnaney Presenter: Michael Swanwick mxs@creare.com, Creare LLC, Hanover, NH, USA

O3.2-175

RASA History and Next Generation RASA (RASA 2.0)

History

- Radionuclide Aerosol Sampler/Analyzer (RASA) 1.0 started in 1992 at PNNL
- CTBT Radionuclide (RN) Network started in 2000
- Uses impact/HEPA style filter

<u>Need</u>

- Faster results to match Xenon gas systems
- Higher flow rate
- Lower power consumption

Results

- Creare has developed multiple systems using electrostatic precipitators (ESPs)
- Higher flow rate with at least 80% collection efficiency
- Reduced collection time (if needed)
- Reduced power consumption
- Multiple samples/day while preserving original sensitivity
- Flexible design






Michael Swanwick, Clive Devoy, Katharine Fergusson, Jessica Elliott, Sheldon Stokes, Kenneth McEnaney Presenter: Michael Swanwick, mxs@creare.com, Creare LLC, Hanover, NH, USA

O3.2-175

Electrostatic Precipitator: Concept

Radionuclide Aerosol Sampler Analyzer (RASA) Impact Filter Replacement

1. Capture Airborne Particles



Advantages

High and Tunable Collection Efficiency
Low Pressure Drop and Low Power Draw
Collection on Thin Material

Challenges

Requires High Voltage
Trace Ozone Produced

Advanced Electrostatic Precipitator Design






Michael Swanwick, Clive Devoy, Katharine Fergusson, Jessica Elliott, Sheldon Stokes, Kenneth McEnaney Presenter: Michael Swanwick mxs@creare.com, Creare LLC, Hanover, NH, USA

O3.2-175


Electrostatic Precipitator: Design, Build, and Test

Generation 0 2018



Proof of Principle System

Generation 1 2022



Full Scale Prototype

Generation 2 2025



Size, Efficiency, and Power Improvements

This work is sponsored by U.S. Defense Threat Reduction Agency (DTRA)
SBIR Contract # HDTRA223C0004
DISTRIBUTION STATEMENT: Cleared for Release



Michael Swanwick, Clive Devoy, Katharine Fergusson, Jessica Elliott, Sheldon Stokes, Kenneth McEnaney Presenter: Michael Swanwick mxs@creare.com, Creare LLC, Hanover, NH, USA

O3.2-175

Electrostatic Precipitator: Design, Build, and Test

Flexible Design

- Number, length, and height of flow channels
- Air flow rates
- Corona wire and E-field plate voltages
- Optional stand-alone version for manual stations


System Highlights

- Flexible webs
- Compatible with single or dual detectors
- ~600 samples between spool reloading
- Compact design
- Prototype size: 2.4 m (8 ft) from floor to duct



This work is sponsored by U.S. Defense Threat Reduction Agency (DTRA)
SBIR Contract # HDTRA223C0004
DISTRIBUTION STATEMENT: Cleared for Release

High Voltage Rail/Wiring







Michael Swanwick, Clive Devoy, Katharine Fergusson, Jessica Elliott, Sheldon Stokes, Kenneth McEnaney Presenter: Michael Swanwick mxs@creare.com, Creare LLC, Hanover, NH, USA

O3.2-175


Electrostatic Precipitator: Design, Build, and Test


Web Design

- Multiple webs on three shelves (~600 samples)
- · Fold into flow area
- Combine and fold out of flow area

Combined Webs







Back Side





This work is sponsored by U.S. Defense Threat Reduction Agency (DTRA)
SBIR Contract # HDTRA223C0004
DISTRIBUTION STATEMENT: Cleared for Release



Michael Swanwick, Clive Devoy, Katharine Fergusson, Jessica Elliott, Sheldon Stokes, Kenneth McEnaney Presenter: Michael Swanwick mxs@creare.com, Creare LLC, Hanover, NH, USA

O3.2-175


Electrostatic Precipitator: Design, Build, and Test


Particle Collection

- Well over 80% collection efficiency at flow rates > 2000 m³/hr
- · Live continuous measurement at inlet and outlet
- Tested in high humidity and high atmospheric particle concentration

Power Draw

- Able to run on a series of small box fans (quiet)
- Under 100W (Collection System) for CTBT min of 500 m³/hr (not including computer or detector)
- Under 1kW (Collection System) for 2000 m³/hr










Michael Swanwick, Clive Devoy, Katharine Fergusson, Jessica Elliott, Sheldon Stokes, Kenneth McEnaney Presenter: Michael Swanwick mxs@creare.com, Creare LLC, Hanover, NH, USA


O3.2-175


Electrostatic Precipitator: Sample Packaging

Prototype Design

- Compact presentation to detector(s)
- Flexible for multiple different sample intervals
- Ensures Sample Integrity
- Worked with University Capstone projects on design concepts











Michael Swanwick, Clive Devoy, Katharine Fergusson, Jessica Elliott, Sheldon Stokes, Kenneth McEnaney Presenter: Michael Swanwick mxs@creare.com, Creare LLC, Hanover, NH, USA

O3.2-175

Electrostatic Precipitator: Next Steps

Testing and Demonstration

- · Testing in Variety of Weather Conditions
- Demonstration in Relevant Environment

System Integration

- Combine ESP with Sample Packaging System and Detector(s)
- Full Automation

Collaboration/Funding

- U.S. Defense Threat Reduction Agency (DTRA)
- Pacific Northwest National Laboratory (PNNL)
- Desert Research Institute (DRI)

CTBT SnT2025 Posters

- P3.2-880 RASA 2.0: A Next Generation Aerosol Sampler/Analyzer Update Lance Lidey (PNNL)
- P3.2-176 Acoustic Agglomeration of Aerosol Particles in Benefit of RASA 2.0 Michael Swanwick (Creare)



